Christmas decoration with music

duration: 30 - 60 minutes
age: 7 - undefined years

A Christmas ornament that can play Christmas tunes.

undefined

tools
- ☐ soldering iron
- ☐ cutting pliers
- ☐ glue gun
- ☐ laser cutter

materials
- ☐ PX088 melody chip
- ☐ battery holder (3v)
- ☐ small speaker
- ☐ 100nf capacitor
- ☐ S8050/2N2222 transistor
- ☐ wood

① Solder wires to your speaker

- ● Cut about 4 cm from the wires of the battery holder.
- ● Solder the cut-offs to your speaker.

2 Solder the transistor

- Place the transistor on the back of the circuit board. The legs need to be slightly bent open.

- Solder the transistor as shown in the photos. Pay close attention to where the flat side is.


3 Tin the pads

- Apply some tin to the 1st, 4th, and 5th pad from the left.

4 Solder the speaker, transistor, and battery holder

● Soldering multiple wires/legs to one pad can be tricky. A 'third hand' or other way to hold your work can be handy here.

● Tin the ends of all the wires.
● Solder the wires according to the diagram.
● Insert a battery and test it.

5 Design the Christmas ornament

- Open Light Burn.
- Copy a Christmas ornament silhouette from the internet and paste it into Light Burn.
- Right-click on the image and select 'trace'. After tracing, you will have a line drawing.
- Delete the original image.

6 Design the Christmas ornament decoration

- Create a line drawing of a background as in the previous step.
- Duplicate the ornament and place it over your background.
- Adjust the background so it fits nicely over the ornament.
- Select the ornament and the background and click the 'boolean intersection' button.
- You now have a background that fits perfectly into the ornament.
- Create as many layers as you want in this way.
- Cut the layers with a laser cutter.

7 Gluing

- Glue the layers of wood together.
- Glue the speaker, chip, and battery on the back.
- Done! Hang your ornament somewhere or give it to someone.